



Instructions *Self Adhesive Carpet*



Step 1.
 Use a sheet of paper or thin card to create a template of the area you wish to cover. This may take a number of attempts to get perfect.



Step 2.
 Once you have your master template, mark the top to ensure you have the template the right way up later. **IMPORTANT!**



Step 3.
 With the top side of your template **FACE DOWN**, draw round your template onto the backing of the carpet with a soft pencil.



Step 4.
 Carefully cut out the carpet using the guide lines you have drawn on the backing sheet. Then test that it fits properly **BEFORE** you start sticking it down.



Step 5.
 Peel the backing sheet away from one corner by just a couple of inches and fold the peeled section as flat as you can, as shown.



Step 6.
 Reposition the carpet carefully into place without the exposed adhesive making contact with the floor.



Step 7.
 Once the carpet is in place, rub the contact area gently down.



Step 8.
 Lift up the loose edge of the carpet until you find the folded edge of the backing sheet.



Step 9.
 Start by pulling the backing sheet a couple of inches at a time before rubbing down each section until the job is complete.